

Table 3.3 Specific fuel consumption, C

Typical jet SFCs: 1/hr {mg/Ns}	Cruise	Loiter
Pure turbojet	0.9 {25.5}	0.8 {22.7}
Low-bypass turbofan	0.8 {22.7}	0.7 {19.8}
High-bypass turbofan	0.5 {14.1}	0.4 {11.3}